




SUGGESTED BATHTUB DRAIN INSTALLATION

<p>A. Skirted, Pedestal & Modern One-Piece Jetted Tubs with Integrated Overflow Quick Fit Drain Connector (not supplied) Apply only silicon caulk under drain basket flange, do not use plumbers' putty.</p>  <p>Tail pipe not included Use brass nut at bottom to tighten drain to tub.</p>	<p>Drain Hub Connector (not supplied) Apply only silicon caulk under drain basket flange, do not use plumbers' putty. Recommended Hub Fitting would be WATCO 11607 Sch40 PVC Hub Adapter or similar. Remove the brass washer from the drain basket if using the hub.</p> 
<p>B. Clawfoot Jetted Tubs with Integrated Overflow. Downpipe can connect to either a regular 1.5" Slip Joint or Quick Connect drain as below (not supplied).</p> 	<p>Drain parts supplied with your Jetted clawfoot tub, Pop-up drain with tail-piece.</p> 