



Instruction and Installation Guide

Serial Number:

Model:

Date of Manufacture:

This manual shall be removed only by the final user prior to using the unit.

Tubs meet or exceed ANSI Z124.1.2: CSA B45.0-02 & CSA B45.5-02

UL Listed

SANSIRO AIR JETTED TUB MANUAL

TABLE OF CONTENTS

Serial Number Details...Page 1

Table of Contents...Page 2

Warranty...Pages 3 & 4

Safety...Page 5

Technical and Leveling...Page 6

For further installation instructions, please view other technical documents for pedestal, claw foot, drain, supply line, faucet installation etc. supplied with the product.

All installations should be carried out by a qualified, licensed contractor in accordance with local code requirements.

SANSIRO AIR JETTED TUB MANUAL

WARRANTY

BOFD Inc. (the "Company") extends a non-transferable limited warranty to the original purchaser (the "User" who purchases the unit for personal or single family residential use as follows). On Labor limited warranty, the company shall, at its election, send a technician or locally appointed service company to repair or replace any failed factory fitted component as described above due to workmanship. On Limited Parts warranty the company shall, at its election, send the user either a replacement cartridge or entire part.

Air jetted tub warranties are 25 years on tub body and 2 years parts on electrical and one year labor on electrical.

The Company warranties can only be transferred if purchased by a developer or builder and on receipt of prior written confirmation of such by the company. Warranty coverage commences on the date the unit was originally purchased by the user and upon receipt by the company of a completely filled out **Warranty Registration Document** as described herein.

Warranty Exclusions and Limitations

The limited warranty shall not cover, without limitation, damage from failure to install in accordance with the company's instructions, fading from exposure to direct sunlight, damage from use of abrasive cleaning agents, damage from improper handling, abuse, misuse, neglect, accident or natural disaster, damage due to improper handling, installation or subsequent movement after initial installation, alteration from original design or failure to follow company recommended maintenance and cleaning of metallic coated or plated hardware, defects, damage or failure caused by the common carrier, installer, user or other person, pets, or rodents. In addition, the company shall not be responsible for incidental damage or consequential damages or losses arising from any cause including but not limited to water damage to carpet, ceiling, tiles, marble, wood flooring, loss of use etc., including its own negligence. Warranty coverage is provided in the United States and Canada.

Exclusion of Implied Warranties

Implied warranties or merchantability and fitness for a particular purpose are disclaimed altogether or to the fullest extent allowed by law. There are no warranties applicable to the products except as expressly stated herein or as implied by applicable state and federal laws. Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of special, incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Responsibilities of Others

The company is not responsible for costs to modify any product to obtain any code approvals, such as city, county or state building codes in the USA.

Warranty Card Registration: In order to validate this warranty. The warranty registration card must be completely filled out and returned within 30 days from original purchase date or must be completed and registered through our website.

SANSIRO AIR JETTED TUB MANUAL

Warranty Service

As well as its' own factory trained technical staff, the company maintains a list of independent service personnel to perform required warranty service repairs. Such firms are not agents or representatives of the company and cannot bind the company by words or conduct. The company will provide the warranty service described herein when the following conditions have been met:

- a) the failure is of a nature or type covered by the warranty.
- b) the user has informed the company of the nature of the problem during the warranty period.
- c) In order to obtain warranty service, please contact the company.

All replacement parts, equipment, and repairs shall assume the remaining warranty period of the parts replaced. The company's warranty obligation shall be discharged upon tender of replacement or repair.

Please remember to fill out the **Warranty Registration Document** available here or to request one by mail.

SAFETY

Important Safety Instructions

1. **DANGER:** To reduce the risk of injury or drowning, do not permit children to use this unit without adult supervision.
2. **DANGER:** Do not submerge your head under water or wash your hair in the bathtub.
3. **WARNING:** Do not use alcohol, drugs or medication before or during the use of a bathtub.
4. **WARNING:** Do not allow appliances such as a hair dryer, lamp, radio etc. within 5 feet of the bathtub.
5. **WARNING:** There is a risk of hyperthermia and possible drowning with a water temperature in excess of 38 degrees Celsius. This temperature may also be injurious to your health if you are suffering from certain medical conditions. Please consult your physician if you are in doubt.
6. **WARNING:** If you suffer from headache, dizziness or nausea, get out of the bath and take a cool shower. You may be suffering from hyperthermia if the water in your bath has been too hot. If the problem persists, please consult your doctor.
7. **WARNING:** Pregnant women or persons with health issues should consult their physician before using jetted or hydrotherapy tubs

SANSIRO AIR JETTED TUB MANUAL

TECHNICAL

Every aspect of every tub that leaved the BOFD factory has been fully tested and inspected before packing.

Tub leveling

Note: To ensure correct usage and enjoyment of your tub, it is important to correctly level your bathtub.

1. There are four leveling pads on the pedestal base and one on each claw foot. These should be adjusted accordingly to allow the tub to sit perfectly level on the floor.

Electrical

- The blower/chromo therapy lights require a single 10 amp dedicated CFCI placed at least 12" above floor level which should be in accordance with all local authority requirements.
- The blower is controlled by an air switch located on the tub edge.
- The twin chromo therapy lights are activated by their own control button also mounted on the tub
- The tub is supplied with 3' of electrical cable running out of the rear area of the tub where the feet are located.

Plumbing

- The standard faucet is connected to the water supply lines using two flexible lines that will exit the bottom of the tub and connect to the two supply stop valves included with the tub package. See drawing for the specific tub to determine rough-in dimensions.
- A 1.5" drain connector is supplied for attaching to the tub drain to fit into the floor drain pipe. Also supplied is a decorative floor cover.
- If not using a thermostatic faucet, we recommend installing a thermostatic control valve into the hot water supply line to avoid possible scalding.

Blower

- Depending on the package purchased, the blower may be one, two or three speed. If single speed, it will not have an automatic purge cycle.
- The automatic purge cycle on multi-speed blowers will begin 30 minutes after switching off the blower and it will run for 5 minutes. If interrupted, it will re-set and run again after another 30 minutes.

SANSIRO AIR JETTED TUB MANUAL

General Care

1. In order to preserve the glossy finish of you new bathtub, never use abrasive cleaners or cleaners containing a scouring powder.
2. Never use steel wool, acetone, window cleaning products, ammonia, paint thinner or mineral oil on your bathtub or fixtures.

Cleaning Your Bathtub

1. Clean your tub after each use.
2. Use a soft sponge and a liquid detergent like Simple Gree.
3. Wash with warm water to remove all marks.
4. Make certain your chosen detergent is suitable for acrylic surfaces.
5. Always rinse out the tub with fresh water after cleaning.
6. After rinsing, run the blower to clear the water lines of any water that may be retained in the pipe lines.

Blower Access for Maintenance

- There are 8 hidden screws under the lip of the tub. When removed, the inside shell of the tub can be lifted out to perform any repairs.

Please retain these instructions

WARNING: This manual shall only be removed by the final user prior to using the unit.