





INCLUDED WITH YOUR BATHTUB and WHAT IT IS FOR

| | |
|---|--|
|  | <p>Rubber Drain Cover. For convenience and to allow you to fully test your tub before installation, we supply this cover for your drain. Should you prefer, the actual drain supplied with the tub can be used.</p> |
|  | <p>Pilot Drill Bit – Acrylic Tubs Only. Should you decide to attach the electrical cord/cords on a wall outside the tub, you will need to drill holes in the acrylic outer shell or pedestal base. After you determine the correct position, mark off and use the pilot bit to make an initial guide hole. Must be 1.5” above floor. Before drilling, make sure there are no objects on the other side.</p> |
|  | <p>Hole Saw – Acrylic Tubs Only. After completing the pilot hole, use the hole saw to slowly and carefully make the hole/holes which will be large enough for the plug/plugs to go through. Rough edges can be softly sanded.</p> |
|  | <p>Rubber Grommet. Push the plug through the grommet and attach the rubber grommet to the inside of the hole to protect the electrical cable. Two grommets are supplied with Hydro-Spa bathtubs</p> |
|  | <p>Velcro Pads. We include Velcro pads that should be connected to the leveling feet. Only remove the underside of the pads when the tub is being placed to connect the drain. These pads will prevent any lateral movement of the tub.</p> |
|  | <p>Drain. The pop-up drain can be connected to a standard drain hub or used with a Quick Connect Drop-in Drain. The brass nut on the bottom of the drain basket should not be used if the drain connection is via a Hub fitting. Use only Silicon caulk to seal the underside of the drain basket flange to the tub, do not use plumbers’ putty.</p> |

WHAT IS INCLUDED WITH YOUR BATHTUB

HYDRO-SPA BATHTUBS

| | |
|---|---|
| <p>1. Remote Control</p> | <p>The remote control will have air on/off with speed variation, water on/off and chromotherapy. In-line water heater and ozone activate automatically during jetting.</p> |
| <p>2. Wireless Receiver is Factory Fitted Under the Tub</p> | <p>The wireless receiver is factory fitted under the bathtub and must connect to a 110v - 15-amp GFCI. This receiver will operate the Pump, Blower, Chromotherapy Light and Ozone Generator. The Heater uses the second plug. The wireless receiver and heater can be connected to electric supplies placed under the tub only when the outlets are protected by easily accessible remote GFCI's. Or, either can be connected to GFCI wall sockets with the electrical cord coming through the shell of the tub or pedestal of the tub.</p> |
| <p>3. TWO x 6' Male/Female 15-amp electrical cord</p> | <p>To assist with electrical connection during testing before installation. One for wireless receiver, the other for the heater.</p> |
| <p>4. Rubber Drain Cover</p> | <p>Use when testing before installation</p> |
| <p>5. Pilot Drill Bit</p> | <p>If you chose to connect the electrical to a wall socket, use this pilot bit to drill the initial hole before using the hole saw</p> |
| <p>6. Hole Saw</p> | <p>After the pilot hole is made, use the hole saw to drill the hole/holes for the electric cord/cords to fit through</p> |
| <p>7. TWO x Rubber Grommet</p> | <p>To protect the electric cables coming through the tubs shell, attach the rubber grommet to the holes.</p> |
| <p>8. Slotted Brass Drain</p> | <p>This is the drain for your tub</p> |
| <p>9. Faucet Supply Line Nipples and Valves</p> | <p>If you order a clawfoot tub with a factory fitted faucet, these water supply line valves will fit under your clawfoot tub and connect to the factory fitted flex lines reaching from the deck mounted faucet to the water supply lines</p> |
| <p>10. 4 x Velcro Pads on pedestal and skirted 6 x Velcro Pads on one-piece modern</p> | <p>We include Velcro pads that should be connected to the leveling feet. Only remove the underside of the pads when the tub is being placed to connect the drain. These pads will prevent any lateral movement of the tub.</p> |

OZONE SANITIZING – If your tub is fitted with ozone, it will automatically be connected to the blower or water pump and will activate during jetting only.

IN-LINE HEATER – If your tub is fitted with an in-line heater, it will automatically activate during jetting only.